



BLVD
Mini Bluetooth® Jukebox
VDTJ-1000



Instruction Manual

Please read carefully before use and keep for future reference

WARNING




CAUTION: To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.



This equipment is a Class II or double insulated electrical appliance. It has been designed in such a way that it does not require a safety connection to electrical earth.

Important Safety Instructions

1. Read these instructions -All the safety and operating instructions should be read before this product is operated.
2. Keep these instructions - The safety and operating instructions should be retained for future reference.
3. Heed all warnings - All warnings on the appliance and in the operating instructions should be adhered to.
4. Follow all instructions - All operating and use instructions should be followed.
5. Do not use this apparatus near water - The appliance should not be used near water or moisture - for example, in a wet basement or near a swimming pool, and the like.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Protect the power cord from being walked on or pinched particularly at the plugs, power outlets, and at the point where they exit from the apparatus.
10. Only use attachments/accessories specified by the manufacturer.
11. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart or rack is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
12. Unplug the apparatus during lightning storms or when unused for long periods of time.
13. Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
14. The mains plug is used as disconnect device, the disconnect device shall remain readily operable.
15. **WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall not be placed on apparatus.
16. The use of the equipment in moderate climate.
17. The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, tablecloths, curtains, etc.
18. Do not place open flame sources, such as lighted candles, on the apparatus.
19. The symbol with  indicates AC voltage.
20. **CAUTION:** These servicing instructions are for use by qualified service personnel only. To reduce the risk of electric shock do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so. **Caution:** For pluggable equipment, the socket-outlet shall be easily ACCESSIBLE



This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of non-insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock. Warning: To reduce the risk of electric shock, do not remove cover (or back) as there are no user-serviceable parts inside. Refer servicing to qualified personnel. The exclamation point within and equilateral triangle is intended to alert the user to the presence of important operating and maintenance instructions in the literature accompanying the appliance.



TABLE OF CONTENTS

| | |
|-----------------------------------|---|
| FEATURES | 3 |
| SPECIFICATIONS | 3 |
| PRODUCT OVERVIEW | 4 |
| SETUP & BASIC OPERATION | 5 |
| LISTEN TO BLUETOOTH® DEVICE | 5 |
| LISTEN TO AUX DEVICE | 6 |
| LIGHT OPERATION | 6 |
| TROUBLESHOOTING GUIDE | 7 |
| FCC NOTICE | 8 |
| IC STATMENT | 8 |
| CAUTION ON MODIFICATION | 9 |
| SUPPORT | 9 |

FEATURES

The BLVD Mini Bluetooth® Jukebox features a Classic Jukebox Design in a convenient size. Bluetooth® lets you stream music from your Smart Device through the built in speakers. And the Multi-Mode Color Changing LED Lighting provides an eye-catching look.

- Bluetooth® connectivity allows you to stream music from another source up to 33 feet.
- Color Changing LED Lighting
- Classic Jukebox Styling
- Built in Speaker for playback convenience.

SPECIFICATIONS

| | |
|----------------------------------|--|
| Product Name | BLVD (Mini Bluetooth® Jukebox) |
| Bluetooth® Version | V5.4 |
| Bluetooth® Frequency | 2.402 GHz - 2.480GHz |
| Bluetooth® Transmission Distance | Up to 33 Feet (10 Meters)* |
| Input | Aux In |
| Built-in Speaker | 3" X 1 |
| Speaker Output Power | 3W |
| Power Source | Input: DC 5V/1A |
| Battery | Lithium 3.7V 1200mAh 4.44Wh |
| Accessories Included | User Manual, Quick Set Up Guide, USB-C Cable |


**Distance may vary depending on any objects or interference between devices.*

SPECIFICATIONS AND ACCESSORIES ARE SUBJECT TO CHANGE WITHOUT NOTICE


PRODUCT OVERVIEW

1. **⏻/▶II:** Power ON/OFF / Play / Pause button
2. **VOLUME - / SKIP:** Decrease volume / Reverse
3. **VOLUME + / SKIP:** Increase volume / Forward
4. **LIGHT MODE:** Press to turn on colorful LED lights. Long press to turn off LED lights.
5. **AUX IN:** Aux in Input. Plug in external device
6. **BT/AUX IN INDICATOR:** BT mode - Blue light, Aux-In mode - Green light
7. **USB-C Port:** Connect USB Cable to charge device (USB Power Adapter not included)

Front View



Rear View





SETUP & BASIC OPERATION

SETUP

- Connect the USB Cable and Charge the device for a minimum of 3 hours

BASIC OPERATION

1. Press and hold the  button to turn the unit on.
2. Press the Volume -/+ Buttons to adjust to the desired sound level.
3. Press the hold  button to turn the unit off.

LISTEN TO A BLUETOOTH® DEVICE

In Bluetooth® mode, this unit can enjoy music from external devices which have a built-in Bluetooth® feature.

GETTING CONNECTED USING BLUETOOTH®

1. The device will automatically enter into Bluetooth® pairing mode when the device is turned on. The BT/AUX light will flash Blue.
2. Turn on the external device and activate the Bluetooth® function.
3. Search for and select "VICTOR VDTJ-1000" on the paired devices list. If prompted for a password, enter "0000" and then press "OK" on your external device.
4. After a few seconds your Bluetooth® connection will be complete. A rising tune will indicate a successful connection has been made and the BT/AUX light will be a solid blue.
5. Turn on the music player program on your external device and set it play.

Normally, you can control music playback with the Volume -/+ Skip Buttons on the apparatus. However, some buttons may not work due to the variable music player program.

Now enjoy the fun!

LISTEN TO AN AUX DEVICE

In AUX (auxiliary) mode, this unit can play audio from an external audio source (iPod, MP3 Player, Portable CD Player, etc.)

There is an **AUX IN** jack on the front of unit. When connecting a device that has a headphone jack, use the cable with 3.5mm plugs on either end with the front AUX IN jack.

1. Plug one end of the AUX IN cable (not included) into the AUX IN jack. The device will automatically enter AUX IN mode. Then BT/Aux indicator will turn Green

2. Plug the other end of the cable into the headphone jack of the external audio source.

Note: All operations are only available on your external device.

3. Press “Power/Play/Pause” key to mute/unmute, press +/- to increase or decrease the volume

4. When done, unplug the Aux in cable from the device, and the device will automatically revert back to BT mode.

LIGHT OPERATION

You can control the LED light by using the LIGHTS button.

- Press “LIGHTS” button to turn on light effect (Device must be on), press “LIGHTS” button to change light mode (There are 10 different light modes)
- Press and hold the button to turn off the LED lights.

TROUBLESHOOTING GUIDE

| | Symptom | Possible Cause | Solution |
|-----------|--|--|--|
| GENERAL | •Unit will not power on. | •Battery is not charged | •Charge the battery |
| | •No sound output from speakers. | •The volume level is set too low. •The input selector does not match the playback source. | •Adjust the volume. •Select the correct input source. |
| | •Noise/Distortion in sound output. | •The unit is too close to a TV set or another interfering device. | •Turn off the TV or other appliance and relocate the unit. |
| | •Unit fails to respond. | •It might result from external factors such as ESD (Electro-static discharge). | •Disconnect the power cord and external audio device. Re-plug the power cord after one minute |
| | | | |
| AUX | •No sound output with external audio device plugged into rear AUX in jack. | •AUX in jacks is unplugged. | •Plug the AUX in Jack. |
| BLUETOOTH | •No sound | •The unit is not switched to Bluetooth mode •Your device's and/or the unit's volume is not turn up. •Your device is too far from the unit or there're some obstacles between your device and the unit. | •Ensure the unit is switched to BT mode. •Move your Bluetooth device closer to unit •Turn up the volume on your portable device and/or the unit. •Turn OFF your Bluetooth device and unit. Then lower them both back ON |
| | •Sound has a lot of static | •Your device is too far away | • Bring your device closer to the unit |
| | •Unable to pair with a Bluetooth device | •Your device doesn't have Bluetooth connectivity. •The Bluetooth pairing is not successful | •Confirm that your device is Bluetooth compatible. •Re-pair the unit and device again. |

FCC NOTICE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

IC STATEMENT

This device complies with RSS247 of Industry Canada. Cet appareil se conforme a RSS247 de Canada d'Industrie. This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. appareils radio exempts de licence.

Son fonctionnement est sujet aux deux conditions suivantes: (1) le dispositif ne doit pas produire de brouillage prejudiciable, et (2) ce dispositif doit accepter tout brouillage recu, y compris un brouillage susceptible de provoquer un fonctionnement indesirable.

The device must not be co-located or operating in conjunction with any other antenna or transmitter.

L'appareil ne doit pas etre localise ou fonctionner avec d'autres antennes ou transmetteurs.

This device complies with IC radiation exposure limits set forth for an uncontrolled environment.

Cet appareil est conforme aux limites d'exposition aux rayonnements de la IC etablies pour un inconrole environnement.

The device should be installed and operated with a minimum distance of 20cm between the radiator and your body.

L'appareil doit etre installe et utilise avec une distance minimale de 20 cm entre le radiate et votre corps.

CAUTION ON MODIFICATIONS

Any changes or modifications not expressly approved by the grantee of this device may void the authority granted by the FCC to operate this equipment. Electric and electronic equipment contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment) is not handled correctly. Electric and electronic equipment is marked with the crossed-out trash can symbol, seen below. This symbol signifies that electric and electronic equipment should not be disposed of with other household waste but should be disposed of separately. All cities have established collection points, where electric and electronic equipment can either be submitted free of charge at recycling stations and other collection sites or be collected from the households. Additional information is available at the technical department of your city.



SUPPORT

We do our best to offer high quality products to our customers. If you experience any issues or problems with your product, please contact customer support as many issues can be quickly resolved.

If you have problems with your device, please consult the instructions in this manual. Please also visit us on the web at www.naxa.com to get up to the minute news, alerts, and documentation for your device. For additional assistance, please contact Naxa Technical Support.

Naxa Technical Support

2320 East 49th

St. Vernon, CA

90058

(866) 411-6292

<http://www.naxa.com/supportcenter>

**This product has been manufactured and sold under the responsibility of NAXA ELECTRONICS INC. VICTOR and the DOG & GRAMOPHONE logo are trademarks used under license by NAXA ELECTRONICS INC. Further information at www.victor-brand.com.*

All other products, services, companies, trademarks, trade or product names and logos referenced herein are the property of their respective owners.